

Precision Optical Performance AllnGaP II LED Lamps

Technical Data

HLMP-ELxx HLMP-EHxx HLMP-EDxx

Features

- Well Defined Spatial Radiation Patterns
- Viewing Angles: 15° , 23° , 30°
- High Luminous Output
- Colors:592 nm Amber617 nm Reddish-Orange630 nm Red
- High Operating Temperature: $T_{\rm JLED}$ = +130 $^{\circ}$ C
- Superior Resistance to Moisture

Benefits

- Viewing Angles Match Traffic Management Requirements
- Colors Meet Automotive and Traffic Signal Specifications
- Superior Light Output Performance in Outdoor Environments
- Suitable for Autoinsertion into PC Boards

Applications

- Traffic Management: Traffic Signals
 Work Zone Warning Lights
 Variable Message Signs
- Commercial Outdoor Advertising:
 Signs
 Marquees
- Automotive: Exterior and Interior Lights

Description

Precision Optical Performance AlInGaP II (aluminum indium gallium phosphide) LEDs offer superior light output for excellent readability in sunlight and dependable performance. The AlInGaP II technology provides extremely stable light output over long periods of time.

These LED lamps are untinted, nondiffused, T-1³/4 packages incorporating second generation optics which produce well defined radiation patterns at specific viewing cone angles.



These lamps are made with an advanced optical grade epoxy offering superior high temperature and high moisture resistance performance in outdoor signal and sign applications. The maximum LED junction temperature limit of +130° C enables high temperature operation in bright sunlight conditions. The epoxy contains both uv-a and uv-b inhibitors to reduce the effects of long term exposure to direct sunlight.

 $T-1^3/4$ (5 mm) Precision Optical Performance AlInGaP II LED Lamps Selection Guide

| Typical Viewing Angle 20 ¹ / ₂ | Color and Dominant Wavelength | Lamps Without Standoffs | Lamps With Standoffs | Luminous Intensity Iv (mcd) ^[3,4,5] @ I(f) = 20 mA | |
|---|-------------------------------------|-------------------------|----------------------|---|-------|
| (Deg.) ^[2] | (nm), Typ. ^[1] | (Outline Drawing A) | (Outline Drawing B) | Min. | Max. |
| | | HLMP-EL16-TW000 | HLMP-EL18-TW000 | 2500 | 7200 |
| | | HLMP-EL16-TWR00 | HLMP-EL18-TWR00 | 2500 | 7200 |
| | | HLMP-EL16-TWK00* | | 2500 | 7200 |
| | | HLMP-EL16-TWS00 | | 2500 | 7200 |
| | | HLMP-EL16-TUS00 | | 2500 | 4200 |
| | Amber 592 | HLMP-EL16-TV400** | | 2500 | 5500 |
| | | HLMP-EL16-TVU00 | | 2500 | 5500 |
| | | HLMP-EL16-UX000 | HLMP-EL18-UX000 | 3200 | 9300 |
| | | HLMP-EL16-UXR00 | HLMP-EL18-UXR00 | 3200 | 9300 |
| | | HLMP-EL16-VW000 | | 4200 | 7200 |
| 15° | | HLMP-EL16-VWR000 | | 4200 | 7200 |
| | | HLMP-EL16-VWK00* | | 4200 | 7200 |
| | | HLMP-EL16-VWS00 | | 4200 | 7200 |
| | | HLMP-EL16-VX000 | | 4200 | 9300 |
| | | HLMP-EL16-VXR00 | | 4200 | 9300 |
| | | HLMP-EL16-VX400** | | 4200 | 9300 |
| | | HLMP-EL16-VXK00* | | 4200 | 9300 |
| | | HLMP-EL16-VXS00 | | 4200 | 9300 |
| | | HLMP-EL16-VY000 | HLMP-EL18-VY000 | 4200 | 12000 |
| | | HLMP-EL16-VYR00 | HLMP-EL18-VYR00 | 4200 | 12000 |
| | | HLMP-EL16-VYK00* | | 4200 | 12000 |
| | | HLMP-EL16-VYS00 | | 4200 | 12000 |
| | Red-Orange 615 | | HLMP-EH18-TW000 | 2500 | 7200 |
| | | HLMP-EH16-UX000 | HLMP-EH18-UX000 | 3200 | 9300 |
| | Red 630 | HLMP-ED16-TW000 | HLMP-ED18-TW000 | 2500 | 7200 |
| | | HLMP-ED16-TWT00 | HLMP-ED18-TWT00 | 2500 | 7200 |
| | | HLMP-ED16-UX000 | HLMP-ED18-UX000 | 3200 | 9300 |
| | | HLMP-ED16-UXT00 | HLMP-ED18-UXT00 | 3200 | 9300 |

T-13/4 (5 mm) Precision Optical Performance AllnGaP II Led Lamps (Continued) Selection Guide

| Typical Viewing Angle 2θ 1/2 | Color and Dominant Wavelength | Lamps Without Standoffs | Lamps With Standoffs | Luminous Intensity Iv (mcd) ^[3,4] @ I(f) = 20 mA | |
|---------------------------------------|-------------------------------------|-------------------------|----------------------|---|------|
| (Deg.) ^[2] | (nm), Typ. ^[1] | (Outline Drawing A) | (Outline Drawing B) | Min. | Max |
| | | HLMP-EL25-QS400** | | 1150 | 2500 |
| | | HLMP-EL25-QSU00 | | 1150 | 2500 |
| | | HLMP-EL25-QSK00* | | 1150 | 2500 |
| | | HLMP-EL25-QSS00 | | 1150 | 2500 |
| | | HLMP-EL25-QT000 | | 1150 | 3200 |
| | | HLMP-EL25-QTR00 | HLMP-EL27-QTR00 | 1150 | 3200 |
| | | HLMP-EL25-RU000 | HLMP-EL27-RU000 | 1500 | 4200 |
| | | HLMP-EL25-RUR00 | HLMP-EL27-RUR00 | 1500 | 4200 |
| | | HLMP-EL25-RUK00* | | 1500 | 4200 |
| 23° | Amber 592 | HLMP-EL25-RUS00 | | 1500 | 4200 |
| | | HLMP-EL25-ST000 | | 1900 | 3200 |
| | | HLMP-EL25-STR00 | | 1900 | 3200 |
| | | HLMP-EL25-STK00* | | 1900 | 3200 |
| | | HLMP-EL25-STS00 | | 1900 | 3200 |
| | | HLMP-EL25-SU000 | | 1900 | 4200 |
| | ľ | HLMP-EL25-SUR00 | | 1900 | 4200 |
| | | HLMP-EL25-SU400** | | 1900 | 4200 |
| | ľ | HLMP-EL25-SUU00 | | 1900 | 4200 |
| | | HLMP-EL25-SUK00* | | 1900 | 4200 |
| | | HLMP-EL25-SUS00 | | 1900 | 4200 |
| | ľ | HLMP-EL25-SVK00* | | 1900 | 5500 |
| | | HLMP-EL25-SVS00 | | 1900 | 5500 |
| | | HLMP-EL25-SV000 | HLMP-EL27-SV000 | 1900 | 5500 |
| | | HLMP-EL25-SVR00 | HLMP-EL27-SVR00 | 1900 | 5500 |
| | | HLMP-EL25-TW000 | HLMP-EL27-TW000 | 2500 | 7200 |
| | | HLMP-EL25-TWR00 | HLMP-EL27-TWR00 | 2500 | 7200 |
| | | HLMP-EL25-TWK00* | | 2500 | 7200 |
| | | HLMP-EL25-TWS00 | | 2500 | 7200 |

Notes:

- 1. Dominant Wavelength, λ_{d} is derived from the CIE Chromaticity Diagram and represents the color of the lamp.
- 2. $\theta_{1/2}$ is the off-axis angle where the luminous intensity is one half the onaxis intensity.
- 3. The luminous intensity is measured on the mechanical axis of the lamp
- 4. The optical axis is closely aligned with the package mechanical axis.

5. Tolerance for each intensity bin limit is \pm 15%.

Part numbers in **bold** are recommended for new designs.

- *HLMP-xLxx-xxK00 are selected to amber color bins 2 and 4 only.
- **HLMP-xLxx-xx400 are selected to amber color bin 4 only.

T-13/4 (5 mm) Precision Optical Performance AllnGaP II Led Lamps (Continued) Selection Guide

| Typical Viewing Angle 2θ ¹ /2 | Color and Dominant Wavelength | Lamps Without Standoffs | Lamps With Standoffs | Luminous Intensity Iv (mcd) ^[3,4] @ I(f) = 20 mA | |
|---|-------------------------------------|-------------------------|----------------------|---|------|
| (Deg.) ^[2] | (nm), Typ. ^[1] | (Outline Drawing A) | (Outline Drawing B) | Min. | Max |
| | | HLMP-EH25-QT000 | | 1150 | 3200 |
| | Red-Orange 615 | HLMP-EH25-RU000 | | 1500 | 4200 |
| | | | HLMP-EH27-SV000 | 1900 | 5500 |
| | | HLMP-EH25-TW000 | HLMP-EH27-TW000 | 2500 | 7200 |
| 23° | | HLMP-ED25-QT000 | | 1150 | 3200 |
| | | HLMP-ED25-QTT00 | | 1150 | 3200 |
| | Red 630 | HLMP-ED25-RU000 | HLMP-ED27-RU000 | 1500 | 4200 |
| | | HLMP-ED25-RUT00 | HLMP-ED27-RUT00 | 1500 | 4200 |
| | _ | HLMP-ED25-SV000 | HLMP-ED27-SV000 | 1900 | 5500 |
| | | HLMP-ED25-SVT00 | HLMP-ED27-SVT00 | 1900 | 5500 |
| | | HLMP-ED25-TW000 | HLMP-ED27-TW000 | 2500 | 7200 |
| | | HLMP-ED25-TWT00 | HLMP-ED27-TWT00 | 2500 | 7200 |
| | - | HLMP-EL31-QRS00 | | 1150 | 1900 |
| | | HLMP-EL31-QS000 | | 1150 | 2500 |
| | | HLMP-EL31-QSR00 | | 1150 | 2500 |
| | | HLMP-EL31-QS400** | | 1150 | 2500 |
| | | HLMP-EL31-QSU00 | | 1150 | 2500 |
| | | HLMP-EL31-QT000 | HLMP-EL33-QT000 | 1150 | 3200 |
| 30° | Amber 592 | HLMP-EL31-QTR00 | HLMP-EL33-QTR00 | 1150 | 3200 |
| | | HLMP-EL31-QTK00* | | 1150 | 3200 |
| | | HLMP-EL31-QTS00 | | 1150 | 3200 |
| | | HLMP-EL31-SV000 | HLMP-EL33-SV000 | 1900 | 5500 |
| | | HLMP-EL31-SVR00 | HLMP-EL33-SVR00 | 1900 | 5500 |
| | | HLMP-EL31-ST000 | | 1900 | 3200 |
| | | HLMP-EL31-STR00 | | 1900 | 3200 |
| | | HLMP-EL31-STK00* | | 1900 | 3200 |
| | | HLMP-EL31-STS00 | | 1900 | 3200 |
| | | HLMP-EL31-SUK00* | | 1900 | 4200 |

Notes:

- 1. Dominant Wavelength, λ_d , is derived from the CIE Chromaticity Diagram and represents the color of the lamp.
- 2. $\theta_{1/2}$ is the off-axis angle where the luminous intensity is one half the on-axis intensity.
- 3. The luminous intensity is measured on the mechanical axis of the lamp package.
- 4. The optical axis is closely aligned with the package mechanical axis.

5. Tolerance for each intensity bin limit is \pm 15%.

Part numbers in **bold** are recommended for new designs.

- *HLMP-xLxx-xxK00 are selected to amber color bins 2 and 4 only.
- **HLMP-xLxx-xx400 are selected to amber color bin 4 only.

T-13/4 (5 mm) Precision Optical Performance AllnGaP II Led Lamps (Continued) Selection Guide

| Typical Viewing Angle 201/2 | Color and Dominant Wavelength | Lamps Without Standoffs | Lamps With Standoffs | Luminous Intensity Iv (mcd) ^[3,4] @ I(f) = 20 mA | |
|-----------------------------|-------------------------------------|-------------------------|----------------------|---|------|
| (Deg.) ^[2] | (nm), Typ. ^[1] | (Outline Drawing A) | (Outline Drawing B) | Min. | Max. |
| | _ | HLMP-EL31-SUS00 | | 1900 | 4200 |
| | | HLMP-EL31-SU400** | | 1900 | 4200 |
| | Amber 592 | HLMP-EL31-SUU00 | | 1900 | 4200 |
| | | HLMP-EL31-SU000 | | 1900 | 4200 |
| | | HLMP-EL31-SUR00 | | 1900 | 4200 |
| | | HLMP-EL31-SVK00* | | 1900 | 5500 |
| | | HLMP-EL31-SVS00 | | 1900 | 5500 |
| | Red-Orange 615 | HLMP-EH31-PS000 | | 880 | 2500 |
| 30° | | HLMP-EH31-QT000 | HLMP-EH33-QT000 | 1150 | 3200 |
| | | HLMP-EH31-RU000 | HLMP-EH33-RU000 | 1500 | 4200 |
| | | HLMP-EH31-SV000 | HLMP-EH33-SV000 | 1900 | 5500 |
| | | HLMP-EH31-SU000 | | 1900 | 4200 |
| | | | HLMP-ED33-QT000 | 1150 | 3200 |
| | | HLMP-ED31-QTT00 | HLMP-ED33-QTT00 | 1150 | 3200 |
| | Red 630 | HLMP-ED31-ST000 | | 1900 | 3200 |
| | | HLMP-ED31-STT00 | | 1900 | 3200 |
| | | HLMP-ED31-SU000 | | 1900 | 4200 |
| | | HLMP-ED31-SUT00 | | 1900 | 4200 |
| | | HLMP-ED31-RU000 | HLMP-ED33-RU000 | 1500 | 4200 |
| | | HLMP-ED31-RUT00 | HLMP-ED33-RUT00 | 1500 | 4200 |
| | | HLMP-ED31-SV000 | HLMP-ED33-SV000 | 1900 | 5500 |
| | | HLMP-ED31-SVT00 | HLMP-ED33-SVT00 | 1900 | 5500 |

Notes


- 1. Dominant Wavelength, $\lambda_d,$ is derived from the CIE Chromaticity Diagram and represents the color of the lamp.
- 2. $\theta_{1/2}$ is the off-axis angle where the luminous intensity is one half the onaxis intensity.
- 3. The luminous intensity is measured on the mechanical axis of the lamp package.
- 4. The optical axis is closely aligned with the package mechanical axis.
- 5. Tolerance for each intensity bin limit is \pm 15%.

Part numbers in **bold** are recommended for new designs.


*HLMP-xLxx-xxK00 are selected to amber color bins 2 and 4 only.

^{**}HLMP-xLxx-xx400 are selected to amber color bin 4 only.

Part Numbering System



Package Dimensions



Absolute Maximum Ratings at $T_A = 25^{\circ}C$

| - A | |
|--|----------------------------------|
| DC Forward Current ^[1,2,3] | 50 mA |
| Peak Pulsed Forward Current ^[2,3] | 100 mA |
| Average Forward Current | 30 mA |
| Reverse Voltage ($I_R = 100 \mu A$) | 5 V |
| LED Junction Temperature | |
| Operating Temperature | 40°C to +100°C |
| Storage Temperature | 40°C to +120°C |
| Wave Solder Temperature | 250° C for 3 seconds |
| _ | [1.59 mm (0.060 in.) below body] |

Notes:


- 1. Derate linearly as shown in Figure 4.
- 2. For long term performance with minimal light output degradation, drive currents between 10 mA and 30 mA are recommended. For more information on recommended drive conditions, please refer to Application Brief I-024 (5966-3087E).
- 3. Please contact your sales representative about operating currents below $10\ \mathrm{mA}.$

Electrical/Optical Characteristics at $T_{A}=25^{\circ}C$

| Parameter | Symbol | Min. | Тур. | Max. | Units | Test Conditions |
|--|-------------------------|------|----------------------|--------------------|-------|--|
| Forward Voltage Amber (λ_d = 592 nm) Red-Orange (λ_d = 617 nm) Red (λ_d = 630 nm) | V _F | | 2.15 2.08 2.00 | 2.4 ^[1] | V | I _F = 20 mA |
| Reverse Voltage | V _R | 5 | 20 | | V | $I_R = 100 \mu A$ |
| Peak Wavelength Amber Red-Orange Red | λ_{PEAK} | | 594 623 639 | | nm | Peak of Wavelength of Spectral Distribution at I _F = 20 mA |
| Spectral Halfwidth | $\Delta\lambda_{1/2}$ | | 17 | | nm | Wavelength Width at Spectral Distribution 1/2 Power Point at I _F = 20 mA |
| Speed of Response | $	au_{ m s}$ | | 20 | | ns | Exponential Time Constant, e ^{-t/τ} s |
| Capacitance | С | | 40 | | pF | $V_F = 0$, $f = 1 \text{ MHz}$ |
| Thermal Resistance | $R\Theta_{J	ext{-PIN}}$ | | 240 | | °C/W | LED Junction-to-Cathode Lead |
| Luminous Efficacy ^[2] Amber Red-Orange Red | ην | | 500 235 155 | | lm/W | Emitted Luminous Power/Emitted Radiant Power at I _f = 20 mA |

Notes:

- 1. For options -xxRxx, -xxSxx, -xxTxx, -xxUxx, -xxWxx, -xxYxx, max forward voltage (Vf) is 2.6 V. Refer to Vf bin table.
- 2. The radiant intensity, I_e , in watts per steradian, may be found from the equation $I_e = I_v/\eta_v$, where I_v is the luminous intensity in candelas and η_v is the luminous efficacy in lumens/watt.










Figure 2a. Forward Current vs. Forward Voltage for Option -xxRxx, -xxSxx, -xxTxx, -xxUxx, and -xxVxx.








Figure 2b. Forward Current vs. Forward Voltage.

Figure 3. Relative Luminous Intensity vs. Forward Current.

Figure 4. Maximum Forward Current vs. Ambient Temperature. Derating Based on $T_{JMAX}=130\,^{\circ}\text{C}.$




Figure 5. Representative Spatial Radiation Pattern for 15 $^{\circ}$ Viewing Angle Lamps.




Figure 6. Representative Spatial Radiation Pattern for 24° Viewing Angle Lamps.




Figure 7. Representative Spatial Radiation Pattern for 30° Viewing Angle Lamps.

Intensity Bin Limits (mcd at 20 mA)

| | - | |
|-------------|-------|-------|
| Bin Name | Min. | Max. |
| Р | 880 | 1150 |
| Q | 1150 | 1500 |
| R | 1500 | 1900 |
| S | 1900 | 2500 |
| Т | 2500 | 3200 |
| U | 3200 | 4200 |
| V | 4200 | 5500 |
| W | 5500 | 7200 |
| Х | 7200 | 9300 |
| Y | 9300 | 12000 |
| Z | 12000 | 16000 |

Tolerance for each bin limit is $\pm 15\%$.

Amber Color Bin Limits (nm at 20 mA)

| Bin Name | Min. | Max. |
|-------------|-------|-------|
| 1 | 584.5 | 587.0 |
| 2 | 587.0 | 589.5 |
| 4 | 589.5 | 592.0 |
| 6 | 592.0 | 594.5 |

Tolerance for each bin limit is ± 0.5 nm.

Note:

- Bin categories are established for classification of products. Products may not be available in all bin categories.
- 2. Vf Bin table only available for those part number with options -xxRxx, -xxSxx, -xxTxx, -xxUxx, -xxWxx, -xxYxx.

Vf Bin Table^[2]

| Bin Name | Min. | Max. |
|-------------|------|------|
| VA | 2.0 | 2.2 |
| VB | 2.2 | 2.4 |
| VC | 2.4 | 2.6 |

Tolerance for each bin limit is ± 0.05 V.



www.agilent.com/semiconductors

For product information and a complete list of distributors, please go to our web site.

For technical assistance call:

Americas/Canada: +1 (800) 235-0312 or

(916) 788-6763

Europe: +49 (0) 6441 92460 China: 10800 650 0017 Hong Kong: (+65) 6756 2394

India, Australia, New Zealand: (+65) 6755 1939 Japan: (+81 3) 3335-8152 (Domestic/International), or 0120-61-1280 (Domestic Only)

Korea: (+65) 6755 1989

Singapore, Malaysia, Vietnam, Thailand, Philippines, Indonesia: (+65) 6755 2044

Taiwan: (+65) 6755 1843
Data subject to change.
Copyright © 2004 Agilent Technologies, Inc.
Obsoletes 5988-8601EN
June 23, 2004
5989-0661EN